KORYO™

USER'S MANUAL

WARRANTY 1 YEAR

KST 250

Kwik Bite

DETACHABLE

SANDWICH MAKER

Dear Customer,

Congratulations! Thank you for buying this KORYO appliance. Your new Detachable Sandwich Maker has been designed for your convenience. We are sure you will get many years of trouble free service from this appliance.

Before commissioning this device please read this user manual carefully. Please retain this user manual, warranty certificate, sales receipt and if possible carton with the inner packaging.

CONTENTS

Safety precaution 4

Special safety precautions 5

Operation 5

Cleaning and care 6

Specifications 6

Instructions on environment protection 6

Warranty 7

SAFETY PRECAUTION

- Wrong operation and improper handling can cause problems with the appliance and injury to the user.
- Read all safety and operating instructions carefully before use.
- The unit may be used only for domestic purpose. No liability is accepted for damages arising from improper use or incorrect handling.
- Before connecting to the mains, please check whether the type of supply and the mains voltage match with the details given on the nameplate on the appliance.
- Do not immerse the appliance and mains plug in water or other fluids. Should the appliance accidentally fall in to water, pull out the power plug immediately and have the appliance checked by expert before **using it again. There is danger to life from electrical shock!**
- **Do not try to open the housing yourself!**
- Do not use the appliance with wet hands, on moist floor or when the appliance is wet.
- Never touch the power plug with wet or damp hands.
- Check main cable and plug regularly for damages. In case of damages, have the power cord and mains plug changed by the manufacturer, or a qualified expert, in order to avoid danger.
- Do not operate the appliance if the power cable or the mains plug shows damage or the unit has fallen down or has been damaged otherwise. In such cases, bring the unit to the authorized service center for checking and repairs, if necessary.
- Do not ever try to repair the unit yourself, **danger of electrical shock!**
- Do not let the power cord hang over sharp edges and keep it away from hot objects and open flames. Pull the plug to remove it from the wall outlet; do not pull the cable.
- The cable as well as any extension cable required should be run in such a way that there will be no risk of anyone pulling it inadvertently or tripping over it. Ensure that the cable dose not touch hot surfaces.
- If an extension cable is used it must be suitable for the power supply in question. Otherwise it causes overheating of cable and/or plug.
- Place the appliance in a rigid, flat and heat-resistant surface, away from open flames (such as gas oven) and operate it out of reach of children.
- This appliance is neither suitable for commercial use nor for outdoor use.
- Disconnect from mains power supply when not in use and before cleaning.
- Switch off the unit before disconnecting from mains power.
- Never carry the unit from its power cord.
- Use only spare parts recommended by the manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance is intended to be used in household and similar applications such ad:

  > Staff kitchen areas in shops, offices and other working environments;

  > Farm houses;

  > By clients in hotels, motels and other residential type environments;

  > Bed and breakfast type environments.

SPECIAL SAFETY PRECAUTIONS

- **Danger of burns!** Some parts of the device get very hot during operation. Therefore, do not move the appliance while it is operating, and only touch the handle of the appliance.
- Do not leave the appliance unattended while the plug is connected to a power supply.
- The power cable must not touch the hot parts of the appliance during operation.

OPERATION

- Release the lid lock and to lift up the lid.
- You can choose from three exchangeable baking plates: waffle, sandwich and grill.
- Change the plates only once the appliance is entirely cooled down!
- In order to change the plates, move the plate in the direction of the arrow until the baking plates have been released and can be taken out. When inserting the chosen plates make sure that the mounting of the plates fit into the cavities on the hinged side of the appliance. Press down on the plate until it snaps in and is locked again.
- Connect the power plug to a suitable wall socket. The red control lamp will light up.
- During first use, minor smell and smoke may develop. This is harmless and of short duration make sure that there is sufficient ventilation.
- The appliance is fully heated once the green control lamp lights up.
- Release the lid lock and lift up the lid.
- Place the food in the appliance and close it again. Do not overfill the device.
- Make sure that the lock snaps in, so the appliance securely locked.
- During the toasting operation the green control lamp will sporadically light up and extinguish. This indicates that the appliance is heating itself, so as to maintain the desired temperature.
- After use, turn off the appliance and pull the power plug.

CLEANING AND CARE

- Please observe also the safety advices.
- Never use abrasive detergents or sharp utensils.
- Before cleaning the appliance, pull out the power plug and allow the appliance to cool down.
- Remove large food residues that may have stuck to the plates. The plates are equipped with an anti-stick coating that can be damaged by contact with sharp objects. Therefore, only use soft utensils such as spoons made of plastic or wood. Do not use sharp or abrasive or detergents.
- Then the plates can be cleaned with a cleaning agent and hot water.
- Clean the housing of the appliance with soft damp cloth and if necessary with a mild cleanser.
- Do not place the appliance in a dishwasher.
- Never immerse the appliance in liquids.
- Dry the appliance before reconnecting it to a wall socket.
- The appliance can be stored in upright position.

SPECIFICATIONS

Power Supply : 230V AC, 50 Hz

Power Consumption : 700W

INSTRUCTIONS ON ENVIRONMENT PROTECTION

Do not dispose of this product in the usual household garbage at the end of its life cycle; hand it over at a collection point for the recycling of electrical and electronic appliance. The symbol on the product, the instructions for use or the packing will inform bout the methods for disposal. The materials are recycling as mentioned in its marking. By recycling or other forms of re-utilization of old appliances, you are making an important contribution to protect our environment. Please inquire at the community administration for authorized disposal location.

WARRANTY

This product comes with a warranty of 12 months from the date of purchase as specified on the warranty card. This is against all defective material or workmanship. In the event of a defect, Future Value Retail Limited or KORYO Authorized Service Centre undertakes to repair the set, free of charge, during the warranty period.

In the event of a defect developing in the product, contact KORYO Customer Care or KORYO Authorized Service Centre and provide information about the defect, the model number and serial number of the product.

THIS WARRANTY IS VOID IF

1. The completely filled warranty card is not presented to the authorised personnel at the time of servicing of the product.
2. The product is not operated according to the instructions given in the user manual.
3. Defects are caused by improper or reckless use.
4. Modifications or alterations have been made to the product or if the product has been tampered with,in any manner whatsoever.
5. Repairs to the product are carried out by anyone other than an authorised company representative.
6. For defects other than faulty parts or workmanship such as damage due to lightning, abnormal voltage, spillages, dust, accidental damage, etc.
7. The serial number is deleted or altered.
8. Used for any non–domestic purpose.

OTHER TERMS AND CONDITIONS

1. Repairs or replacement will be carried out either by a Future Value Retail Limited authorised customer care centre or by a representative.
2. All expenses incurred in collecting the unit(s) or part(s) thereof from the Customer Service Centre, as well as any other expenses and incidentals will be borne by the customer.
3. Whilst the company will make every effort to carry out repairs at the earliest, it is made expressly clear that the company is under no obligation to do so in a specified period of time.
4. The company or its authorised customer centre reserves the right to retain any part(s) or component(s) replaced at its discretion, in the event of a defect being noticed in the equipment during the warranty

WARRANTY CARD

THIS CARD IS VALID ONLY IF IT IS FILLED IN COMPLETELY,
SIGNED AND STAMPED BY THE DEALER ON DATE OF PURCHASE

MODEL NO : _____ SERIAL NO : _____

CUSTOMER NAME : _____

ADDRESS : _____

_____

_____

PHONE NO : RESIDENCE : _____ OFFICE : _____

INVOICE/CASH BILL NO : _____

DATE OF PURCHASE : _____

CUSTOMER SIGNATURE : _____

DEALER'S STAMP

* For service request kindly contact Customer Care Centre at : 1800-425-7722, 080-26577722
* Please mail in queries to feedback@koryoworld.com

Also Available		
Microwave Oven	Mixer Grinder	Split Air Conditioner
Induction Cook Top	Juicer Extractor	Window Air Conditioner
OTG	Juicer Mixer Grinder	Geyser
Electric Cooker	Slow Juicer	Room Heater
Electric Kettle	Steam & Dry Iron	Immersion Heater
Pop-Up Toaster	Hair Dryer	Hand Blender
Sandwich Maker	Vacuum Cleaner	Fan
Electric Pressure Cooker	Washing Machine	Emergency Light

KORYO™

Imported by:
Future Value Retail Limited
Tower C, 9th Floor, 247 Park, L.B.S. Marg, Vikhroli (West),
Mumbai - 400 083, Maharashtra, India.